



EM24 W1 01

Energy analyzer

USER MANUAL

Contents

| | |
|--|-----------|
| EM24 W1 01 | 5 |
| Description | 5 |
| Structure | 5 |
| EM24 W1 01 use | 6 |
| Introduction | 6 |
| Display | 6 |
| Working with the measurement/info menu | 7 |
| Working with the reset menu | 7 |
| Reset partial meters | 7 |
| Measurement menu - measurement pages | 9 |
| Information Menu | 10 |
| Reset menu | 10 |
| Essential information | 11 |
| Average value calculation (dmd) | 11 |
| Frames | 11 |
| Encryption key | 12 |
| Frontal LED | 12 |
| Maintenance and disposal | 13 |

Information property

Copyright © 2019, CARLO GAVAZZI Controls SpA

All rights reserved in all countries.

CARLO GAVAZZI Controls SpA reserves the right to apply modifications or make improvements to the relative documentation without the obligation of advance notice.

Safety messages

The following section describes the warnings related to user and device safety included in this document:



NOTICE: indicates obligations that if not observed may lead to damage to the device.



CAUTION! Indicates a risky situation which, if not avoided, may cause data loss.



IMPORTANT: provides essential information on completing the task that should not be neglected.

General warnings



This manual is an integral part of the product and accompanies it for its entire working life. It should be consulted for all situations tied to configuration, use and maintenance. For this reason, it should always be accessible to operators.



NOTICE: no one is authorized to open the analyzer. This operation is reserved exclusively for CARLO GAVAZZI technical service personnel.

Protection may be impaired if the instrument is used in a manner not specified by the manufacturer.

Service and warranty

This product was specifically developed to be used with the data acquisition systems provided by Kamstrup. In the event of malfunction, fault, requests for information, contact info@kamstrup.dk or [+45 89 93 10 00](tel:+4589931000).

Download

| | |
|---------------------------------|--|
| This manual | www.productselection.net/MANUALS/UK/EM24_W1_01_im_use.pdf |
| Installation instruction - EM24 | www.productselection.net/MANUALS/UK/EM24_W1_01_im_inst.pdf |


EM24 W1 01

Introduction

Description

EM24 is an energy analyzer for DIN-rail mounting, with configuration joystick and LCD display. The direct connection version (AV2) allows to measure up to 65 A, the CT connection version (AV5) allows to measure up to 34875 A by means of current transformers (5 A secondary output). The wireless M-Bus communication allows to transmit the collected data.

Structure



| Part | Description |
|------|--|
| A | LCD display |
| B | Voltage/current connections |
| C | Joystick |
| D | Selector with pin for MID seal (programming block) |
| E | SMA connector (external antenna version) |
| F | Pins for MID seal (protection covers included) |
| G | External antenna for wireless M-Bus communication |
| H | SMA connector cable (2 m) |

EM24 W1 01 use

Interface

Introduction





EM24 is organized in two menus:

- measurement and information menu: pages used to display the measurement pages, information relevant to the programmed parameters and instrument firmware release
- reset menu: pages used to reset partial meters and dmd calculation.

Display


The display is divided into 3 lines.




| Symbol | Description |
|--|---|
|  | Displaying of phase-to-neutral system voltage |
|  | Displaying of phase-to-phase system voltage |
|  | Displaying of max values |
|  | Displaying of system variables |
| dmd | Displaying of dmd variables |
| EEEE | Overflow. Note: the DMD calculation, the hour-counter and the energy meters functions are inhibited and the alarm outputs are activated. The indication "EEEE" in a single phase variable automatically implies the overflow condition of the relevant system variable, and the PF indication is forced to "0.000". |

Working with EM24 W1 01




Working with the measurement/info menu









Working with the reset menu



Reset partial meters

| Step | Action | Button |
|------|---|---|
| 1 | Power on the energy analyzer | - |
| 2 | Press the joystick for at least 3 seconds |  |
| 3 | In the PASS? page, select the correct password (default 0) |  |
| 4 | Confirm operation |  |

| Step | Action | Button |
|------|-------------------------------------|---|
| 5 | Scroll pages until EnE P.rES |  |
| 6 | Enter the editing mode |  |
| 7 | Select Yes |  |
| 8 | Confirm operation |  |
| 9 | Scroll pages until End |  |
| 10 | Confirm operation to exit |  |

Menu description

Measurement menu - measurement pages

The displayed pages depend on the version and settings.

| Page | Displayed measurements | Description |
|------|---|--|
| 1 | L1-L2-L3 $V_{LN\bar{z}}$ Hz | Phase sequence System phase-neutral voltage Frequency |
| 2 | L1-L2-L3 $V_{LL\bar{z}}$ Hz | Phase sequence System phase-phase voltage Frequency |
| 3 | Tot kWh (+) $W_{\bar{z}}$ dmd $W_{\bar{z}}$ dmd max | Total imported active energy System active power dmd System active power dmd max |
| 4 | kWh A dmd max PArT | Active energy Maximum dmd current Partial active energy |
| 5 | Tot kvarh (+) $VA_{\bar{z}}$ dmd $VA_{\bar{z}}$ dmd max | Total imported reactive energy System apparent power dmd System apparent power dmd max |
| 6 | kvarh $VA_{\bar{z}}$ PArT | Reactive energy System apparent power Partial reactive energy |
| 7 | Total kvarh (-) $VA_{\bar{z}}$ dmd $VA_{\bar{z}}$ dmd max | Total exported reactive energy System apparent power dmd System apparent power dmd max |
| 8 | Total kWh (-) $W_{\bar{z}}$ dmd $W_{\bar{z}}$ dmd max | Total exported active energy System active power dmd System active power dmd max |
| 9 | Hours $W_{\bar{z}}$ $PF_{\bar{z}}$ | Total load operating hours System active power System power factor |
| 10 | Hours $VAR_{\bar{z}}$ $PF_{\bar{z}}$ | Total load operating hours System reactive power System power factor |
| 11 | var L1 var L2 var L3 | Phase 1 reactive power Phase 2 reactive power Phase 3 reactive power |
| 12 | VA L1 VA L2 VA L3 | Phase 1 apparent power Phase 2 apparent power Phase 3 apparent power |
| 13 | PF L1 PF L2 PF L3 | Phase 1 power factor Phase 2 power factor Phase 3 power factor |
| 14 | W L1 W L2 W L3 | Phase 1 active power Phase 2 active power Phase 3 active power |
| 15 | A L1 A L2 A L3 | Phase 1 current Phase 2 current Phase 3 current |
| 16 | V L1-2 V L2-3 V L3-1 | Phase 1-phase 2 voltage Phase 2-phase 3 voltage Phase 3-phase 1 voltage |
| 17 | V L1 V L2 V L3 | Phase 1 voltage Phase 2 voltage Phase 3 voltage |

Information Menu

| Page | Page title | Information displayed |
|------|------------------------|--|
| 1 | CoMM rEV | Firmware revision (communication) |
| 2 | StAtuS | Device status |
| 3 | ModE | Transmission mode |
| 4 | FrAME | Frame type |
| 5 | interVAL | Transmission interval |
| 6 | EnCrYPt | Encryption |
| 7 | id nuM | Identification number for wireless M-Bus communication |
| 8 | CT ratio | CT ratio |
| 9 | 1P/3Pn (2-3-4-wire) | System Connection (2-3-4-wire) |
| 10 | Pulse | LED pulse weight (kWh/kvarh per pulse) |
| 11 | ChEcKSuM | FW checksum for MID certification |
| 12 | Year | Firmware release Year of production |

Reset menu

| Page title | Sub-menu | Description | Values | Default value |
|---------------|----------|-----------------------------------|----------------|---------------|
| Cng PASS | - | Change password | From 0 to 9999 | 0 |
| EnE P.rES | | Partial counter reset | no yes | no |
| rESEt dmd max | | Dmd calculation and dmd max reset | no yes | no |
| End | - | Exit and save | - | - |

Essential information

Measurement management

Average value calculation (dmd)

The system calculates the average value of electrical variables in a set integration interval.

Dmd values are available on display only. The dmd interval is automatically set equal to the transmission interval and it is not synchronized with the transmission interval.

Communication

Frames

The frames are packages of messages sent by EM24 containing the variables measured. The variables and their encryption included in the frame are as follows:

| Variable | Data Format | Engineering unit | DIF [hex] | VIF [hex] | VIFE#1 [hex] | VIFE#2 [hex] | VIFE#3 [hex] |
|--------------------------------|----------------|------------------|-----------|-----------|--------------|--------------|--------------|
| Total imported active energy | 32 bit integer | Wh*100 | 04 | 05 | | | |
| Total imported reactive energy | 32 bit integer | kVarh*0.1 | 04 | FB | 82 | 75 | |
| Total exported active energy | 32 bit integer | Wh*100 | 04 | 85 | 3C | | |
| Total exported reactive energy | 32 bit integer | kVarh*0.1 | 04 | FB | 82 | F5 | 3C |
| Error flag | 8 bit integer | | 01 | FD | 17 | | |

Note: "error flag" is a diagnostic variable used to communicate an overflow condition which makes the measured data invalid:

| Bit | | | | | | | | Meaning | | Notes |
|---------|---|---|---|---|---|---|---------|------------------------|--------------|--|
| 8 [MSb] | 7 | 6 | 5 | 4 | 3 | 2 | 1 [LSb] | 1P system | 3P system | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | No error | | <ul style="list-style-type: none"> N.A. (not available): the bit cannot be set because the relevant measurement is not defined, bit = 0. Frequency out of range is set when occurs an overflow or an underflow of the frequency measured by measuring module. In system 3P, monitored voltages are the L-L voltages and not the L-N voltages. |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 1 | V1N overflow | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 1 | 0 | N.A. | V2N overflow | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | N.A. | V3N overflow | |
| 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 | I1 overflow | | |
| 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 | N.A. | I2 overflow | |
| 0 | 0 | 1 | 0 | 0 | 0 | 0 | 0 | N.A. | I3 overflow | |
| 0 | 1 | 0 | 0 | 0 | 0 | 0 | 0 | Frequency out of range | | |

Encryption

To ensure data privacy and prevent data access by unauthorized parties, you can enable M-Bus wireless communication data encryption. To read the data use the acquisition system provided by Kamstrup.

Essential information

Encryption key

The encryption key is uniquely associated with each device. The key is available on the Kamstrup online portal.

Frontal LED

The frontal red LED flashes proportionally to the active imported energy consumption. Any kind of negative (exported) energy will not be managed by the front LED.

Maintenance and disposal

Cleaning

Use a slightly dampened cloth to clean the display. Do not use abrasives or solvents.

Responsibility for disposal



The product must be disposed of at the relative recycling centers specified by the government or local public authorities. Correct disposal and recycling will contribute to the prevention of potentially harmful consequences to the environment and persons.





CARLO GAVAZZI Controls SpA

via Safforze, 8
32100 Belluno (BL) Italy

www.gavazziautomation.com

