


Proper grounding must be performed to ensure correct measurement.

⚠ Warning! Wrong grounding can lead to unstable and incorrect measurement.


Metal pipe system



Connect straps to both flanges with 6 mm [1/4"] screws.

Bonding/grounding straps are part of delivery and pre-mounted on the water meter.

Plastic pipe system




Use optional grounding rings at both ends.

Grounding rings are not included in delivery (must be ordered separately).



Set up time

Always set time and date after power up.



Check display

Always check that the error symbol disappears in the display.

