

Installation guide

• **Connection of radio
METERTOOL**



Connection of radio METERTOOL

- 1 Start**
Open the software METERTOOL OMNIPOWER®.
- 2 Connect**
Connect an optical read-out head to the USB port on your PC and to the optical port on OMNIPOWER®.
- 3 Import**
Import the encryption keys of the meter.
- 4 The METERTOOL OMNIPOWER® solution**
Select the menu item "Tools".
- 5 The METERTOOL OMNIPOWER® solution**
Select "Enabled" under "Radio control".

Nice to know

If you need help, select **View help** in the menu in the upper left corner

If you need help for connecting an optical read-out head, see **Communication settings**

If you need help for importing encryption keys, see **Importing encryption keys**

If you need help for connecting radio, see **Radio control**

Visit kamstrup.com for further info